



# Application Guide

## **FLEX RS 276 PRIMER SUBSTRATE REQUIREMENTS**

**Flex RS 276 Primer is required for the following substrates prior to applying Flex RS 230 LFM.**

- Concrete
- Asphalt
- Brick
- Masonry Block
- Cement Mortar
- DensDeck®
- Securock®
- OSB
- Wood Plank
- Plywood
- APP Modified Bitumen

### **Surface Preparation prior to application of primer or catalyzed liquid resin**

- Concrete and other masonry surfaces: grind with diamond cup wheel or shot blast
- Gypsum Type Cover Board: remove dust and particulates
- Wood Products: remove dust and particulates
- Metal: clean with Flex all purpose cleaner, roughen with abrasive disc or belt sander
- PVC Pipes: lightly sand , wipe clean
- Glass: lightly sand, clean with Flex all purpose cleaner