



NOTES:

- 1) EXISTING DRAIN BOWL, CLAMPING RING AND DRAIN ACCESSORIES ARE TO BE CLEANED FREE OF ALL CONTAMINATES.
- 2) FLEX MEMBRANE PLATES AND FASTENERS ARE REQUIRED TO BE INSTALLED 12" OC AROUND THE ROOF DRAIN
- 3) FLEX TPO: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

TITLE		STANDARD DRAIN DETAIL	
NAME		DETAIL NO. 4.31	
DRAWN BY:	SK	DATE:	11/2017
APPLICABLE TO FLEX			
ADHERED ROOFING SYSTEMS			
FLEX MEMBRANE INTERNATIONAL		2670 LEISCZ'S BRIDGE RD LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com	