



Note 1: If the mechanical units are of a size that they will crush the insulation, then the insulation below the sleeper must be replaced by wood blocking.

Note 2: Attach mechanical unit to sleeper per equipment manufacturer's instructions.

Note 3: All field welds shall be a minimum of 1-1/2" wide.

Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.

TITLE		WOOD SLEEPER	
NAME:		DETAIL 5.50	
DRAWN BY:	MG	DATE:	3/13/2023
FOR USE IN ALL FLEX			
ROOFING SYSTEMS			
FLEX MEMBRANE INTERNATIONAL		5103A POTTSVILLE PIKE READING, PA 19605 800-969-0108 FLEXROOFINGSYSTEMS.COM	