



NOTE:

- 1) FLEX PRIMER WASH MUST BE APPLIED TO THE SUBSTRATE AND THE BACK OF THE FLASHING MEMBRANE PRIOR TO INSTALLING THE BUTYL TAPE

| | |
|-------------------------------------|---|
| TITLE | Low Height Wall Flashing |
| Name | Detail No. 2.11 |
| Drawn By: | KF |
| Applicable to all Flex Roof Systems | |
| FLEX MEMBRANE INTERNATIONAL | 2670 Leiscz's Bridge Rd. Leesport, PA 19533 800-969-0108 www.flexmembranes.com |