



NOTES:

LOCATE FLEX TERMINATION A MINIMUM OF 8" IN VERTICAL HEIGHT FROM FIELD MEMBRANE.

1. POSITION THE FLEX RHINOBOND PLATE 3 1/2"-4" FROM THE VERTICAL TRANSITION
2. FLEX RHINOBOND IS NOT FOR USE WITH NON-FACED EPS OR XPS INSULATION

TITLE	
PARAPET CURB FLASHING	
NAME	
DETAIL NO. R-4	
DRAWN BY:	DATE:
SK	12/2013
APPLICABLE TO ALL FLEX RHINOBOND ATTACHED ROOFING SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com