



SECUREMENT FASTENED AT
BASE OF WALL OR CURB
ALTERNATE BASE FASTENING

NOTES:

- 1) SEALANT IS A TWO STEP APPLICATION:
 - A) BEHIND TOP OF FLEX FLASHING.
 - B) TOP OF FLEX TERM BAR.
- 2) SEALANT SHALL BE APPLIED TO CLEAN ACCEPTABLE SURFACES.
- 3) FLEX TERM BAR SHALL BE SECURELY ANCHORED WITH GROMMETTED FASTENERS AND PROVIDE ADEQUATE COMPRESSION OF MEMBRANE FLASHING AND SEALANT.
- 4) ALL FLASHING MEMBRANE THAT IS INSTALLED HIGHER THAN 18" VERTICAL MUST BE ADHERED TO SUBSTRATE.
- 5) IF FLASHING HEIGHT IS HIGHER THAN 48" PLEASE REFER TO FLEX DETAIL 2.40.
- 6) FLEX TPO ONLY: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

TITLE WALL FLASHING WITH SURFACE MOUNTED COUNTER FLASHING	
NAME DETAIL NO. 2.11	
DRAWN BY: MG	DATE: 8/2022
APPLICABLE TO ALL FLEX	
ROOFING SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	5103A PITTSVILLE PIKE READING, PA 19605 800-969-0108 FLEXROOFINGSYSTEMS.COM