



NOTES:

- 1) SEALANT IS A TWO STEP APPLICATION:
 - A) BEHIND TOP OF FLEX FLASHING.
 - B) TOP OF FLEX TERM BAR.
- 2) SEALANT SHALL BE APPLIED TO CLEAN ACCEPTABLE SURFACES.
- 3) FLEX TERM BAR SHALL BE SECURELY ANCHORED WITH GROMMETTED FASTENERS AND PROVIDE ADEQUATE COMPRESSION OF MEMBRANE FLASHING AND SEALANT.
- 4) ALL FLASHING MEMBRANE THAT IS INSTALLED HIGHER THAN 18" VERTICAL MUST BE ADHERED TO SUBSTRATE.
- 5) IF FLASHING HEIGHT IS HIGHER THAN 48" PLEASE REFER TO FLEX DETAIL 2.40.
- 6) FLEX TPO ONLY: FLEX TPO CUT EDGE SEALANT IS REQUIRED ON ALL NON FACTORY CUT EDGES OF FLEX TPO

TITLE WALL FLASHING WITH SURFACE MOUNTED REGLET	
NAME	DETAIL NO. 2.10
DRAWN BY:	SK
DATE:	7/2017
APPLICABLE TO ALL FLEX	
ADHERED ROOFING SYSTEMS	
FLEX MEMBRANE INTERNATIONAL	2670 LEISCZ'S BRIDGE RD. LEESPORT, PA 19533 800-969-0108 FlexRoofingSystems.com